

## Thermal Design Challenges Posed by the Four Bed CO2 Scrubber COTS Air-Save Pump



**TFAWS**  
VIRTUAL • 2020

Dan Popok  
Marshall Space Flight Center,  
Linc Research | Jacobs Space Exploration Group (JSEG)  
Engineering Services and Science  
Capabilities Augmentation (ESSCA)  
[dan.popok@nasa.gov](mailto:dan.popok@nasa.gov)

Presented By  
Dan Popok

Thermal & Fluids Analysis Workshop  
TFAWS 2020  
August 18-20, 2020  
Virtual Conference



# Introduction



- The Four Bed Carbon Dioxide (**4BCO2**) scrubber Air-Save Pump (**ASP**) operates as part of the adsorbent bed regeneration cycle.
- ASP removes residual air from the bed for return to the cabin prior to heat and vacuum exposure which removes the CO2, regenerating the bed.
- 4BCO2 employs a Commercial Off-the-Shelf (**COTS**) scroll type air pump
  - Repackaged in an acoustically insulated enclosure to reduce noise
  - Mounted to a cold plate.
- The International Space Station (**ISS**) Low Temperature Loop (**LTL**), operates between 38F and 50F
  - Flows first through a precooler to cool the process air. Precooler performance requires LTL.
  - Then flows through the cold plate, cooling the pump. Acoustic enclosure precludes air cooling, requiring LTL.
- Results in competing ASP thermal design goals:
  - Keep the pump and motor sufficiently cool
  - Avoid forming condensation due to over-cooling.
- Surfaces below 60F typically warrant careful consideration of condensation.
- A test-calibrated thermal model demonstrates such a balanced design is feasible with temperatures above 60F.
- A separate, coupled fluid model predicts the potential for condensation formation, allowing risk assessment of flying with the unmodified design.




# Outline



- 4BCO2 description
- The COTS air pump
- Thermal characterization testing showing condensation risk
- Test correlated thermal model
- Condensation eliminating design mods
- Condensation model and analysis
- Questions?





# 4BCO2 Description





- CO2 scrubber for EXPRESS Rack
- Consists of 4 beds
  - Two CO2 adsorbing beds
  - Two desiccant beds
- Fluid interfaces
  - Avionics air cooling: 18.3C (65F) to 29.4C (85F)
  - LTL cooling: 3.3C (38F) to 10C (50F)
  - Process air: CO2 removed and returned to cabin
  - Vacuum port: disposes extracted CO2
- LTL
  - Cools process air upstream of adsorbent bed
  - Cools the air save pump

# Flight Hardware Assembly











# ASP Purpose




- 4BCO2 operates in two 80 minute half cycles –
  - One adsorbent bed scrubs CO2 while the other regenerates
  - One desiccant bed dries incoming ISS cabin air while the other re-humidifies air going back to the cabin
- ASP participates in adsorbent bed regeneration process
  - For the first 10 minutes: pumps residual air from the adsorbent bed for return to the cabin
  - For the remaining 70 minutes: heaters and vacuum exposure removes CO2, recharging the bed for the next half cycle




## Description of Cycle and Half-Cycle

### One Cycle



Half Cycle A



Half Cycle B




# 4BCO2 Operation



- Flipping through the next 25 slides fairly rapidly to show 4BCO2 operation as “pseudo animation”

# 4BCO<sub>2</sub> Operation (1)




# 4BCO<sub>2</sub> Operation (2)

## Transition out of Air-Save

Half Cycle A  
 Segment A1, Mode 2

Desiccant bed removes moisture from incoming air. Moisture in the Sorbent bed limits adsorption of CO<sub>2</sub> in bed A-2



Valve changes as we exit air-save mode. Air-save vacuum pump turns off.




# 4BCO2 Operation (3)

## Transition out of Air-Save

Half Cycle A

Segment A1, Mode 2




# 4BCO2 Operation (4)

## Transition out of Air-Save

Half Cycle A

Segment A1, Mode 2




# 4BCO<sub>2</sub> Operation (5)

## Adsorption of Bed A-2: Desorption of Bed A-1

Half Cycle A

Segment A2, Mode 3




# 4BCO2 Operation (6)

## Adsorption of Bed A-2: Desorption of Bed A-1

Half Cycle A

Segment A2, Mode 3






# 4BCO<sub>2</sub> Operation (7)

## Adsorption of Bed A-2: Desorption of Bed A-1

Half Cycle A

Segment A2, Mode 3




# 4BCO2 Operation (8)

## Last Segment (CO2 to Vacuum)

Half Cycle A

Segment A3, Mode 4




# 4BCO2 Operation (9)

## End of First Half Cycle

Half Cycle A

Segment A3, Mode 4




# 4BCO<sub>2</sub> Operation (10)

## Transition to Second Half Cycle Air-Save

Half Cycle A

Segment A3, Mode 4

All Valves move position to transition to the next half-cycle






# 4BCO2 Operation (11)

## Transition to Second Half Cycle Air-Save

Temporary Cessation of All Air Flow  
Segment A3, Mode 4




# 4BCO2 Operation (12)

## Transition to Second Half Cycle Air-Save

Half Cycle A

Segment A3, Mode 4




# 4BCO<sub>2</sub> Operation (13)

## Second Half Cycle Air-Save

Half Cycle B  
 Segment B1, Mode 5

Half Cycle is now repeated, but in the opposite direction




# 4BCO<sub>2</sub> Operation (14)

## Transition out of Second Half Cycle Air-Save

Half Cycle B

Segment B1, Mode 5






# 4BCO<sub>2</sub> Operation (15)

## Transition out of Second Half Cycle Air-Save

Half Cycle B

Segment B1, Mode 5




# 4BCO<sub>2</sub> Operation (16)

## Transition out of Second Half Cycle Air-Save

Half Cycle B

Segment B1, Mode 5




# 4BCO<sub>2</sub> Operation (17)

## Adsorption of Bed A-1: Desorption of Bed A-2

Half Cycle B

Segment B2, Mode 6




# 4BCO<sub>2</sub> Operation (18)

## Adsorption of Bed A-1: Desorption of Bed A-2

Half Cycle B

Segment B2, Mode 6




# 4BCO<sub>2</sub> Operation (19)

## Adsorption of Bed A-1: Desorption of Bed A-2


Half Cycle B

Segment B2, Mode 6



# 4BCO2 Operation (20)

Vent to Vacuum  
 Half Cycle B  
 Segment B3, Mode 7




# 4BCO2 Operation (21)

## End of Second Half Cycle

Half Cycle B

Segment B3, Mode 7






# 4BCO2 Operation (22)

## Transition to First Half Cycle

Half Cycle B


Segment B3, Mode 7



# 4BCO2 Operation (23)

## Transition to First Half Cycle

Temporary Cessation of All Air Flow  
Segment B3, Mode 7




# 4BCO<sub>2</sub> Operation (24)

## Transition to First Half Cycle


Half Cycle B

Segment B3, Mode 7




# 4BCO2 Operation (25)

Air-Save  
 Half Cycle A  
 Segment A1, Mode 2



# Repackaging the COTS Pump

- Noise requirements drove repackaging the COTS pump and motor, putting it inside an acoustically insulated enclosure
  - Motor drive board relocated to separate avionics box
  - Motor and point mounted to LTL-cooled cold plate, no fan cooling




## Thermal Limits

- 50C (122F) ambient rating in vendor-supplied form
- 70C (158F) max pump housing
- 65C (149F) max motor housing

## Performance characteristics

- ~75/25 pump/motor heat dissipation split
- Motor efficiency ~75%
- Pump efficiency = low (~4%) since pumping against deadhead vacuum most of the time


# Repackaged Pump and Motor



**Cold plate thermal insulation and acoustic insulation not shown**

# ISS Temperature/Humidity Envelope

- SSP 57000 Rev S, Section 3.9.1 specifies condensation prevention requirements
  - Generally interpreted as avoiding surface temperatures below 15.6C (60F), the worst case cabin air dew point
  - Exceptions permitted if no fungus susceptibility
  - SSP 57000 ISS temperature/humidity environment applies to ISS cabin, but assumed to apply inside the 4BCO2 rack





- Thermal characterization testing with the Flight Unit showed numerous temperatures below 15.6C (60F)



# Flight Unit Thermal Characterization


- Thermal characterization testing with the Flight Unit showed numerous temperatures below 15.6C (60F)



Temperatures below  
 15.6C (60F)



# The Thermal Conundrum





- In fan/air-cooled COTS configuration, possibility exists to treat pump as a simple “component” rated for 50C (122F) ambient conditions.
  - Ensuring rack air temperature less than 50C in vicinity of pump would suffice
  - Rack air < 100% relative humidity and pump temperature always  $\geq$  rack air temperature  $\rightarrow$  no condensation
- Acoustic enclosure and cold plate results in need for thermal balance between competing goals
  - Pump and motor must not get too hot, BUT
  - Need to avoid over-cooling to prevent condensation
  - Acoustic enclosure precludes using avionics air to cool ASP
- LTL temperatures ranging from 3.3C (38F) to 10C (50F) pose a real condensation concern with 15.6C (60F) dew point limit
  - Low LTL temperatures required by pre-cooler performance demands



# ASP Condensation Analysis




- ASP thermal model developed and run with Thermal Desktop (also part of 4BCO2 system level model)
- Model dialed-in to agree with transient thermal characterization test data for hot and cold cases.
- Resulting tuned thermal model used to identify design changes balancing and satisfying the competing thermal goals – *keeping pump and motor sufficiently cool without allowing condensation to form*
- Additional fluid model (Thermal Desktop FloCAD) predicted condensation formation and accumulation for a range of possible worst case conditions




**Cover and insulation removed**

# ASP Power and Heat Dissipation




- Power measured at input to motor controller and used to compute pump and motor heat dissipation
- Assumptions
  - 3.6W controller standby power
  - 85% controller converter efficiency
  - 75% motor efficiency
  - 4% pump efficiency (averaged over 10 minute operation)
  - Linear power variation over 10 minute pump down (higher power when pumping against dead head vacuum)

# Model Calibrated to Test: Pump




Only cold test shown, similar model-to-test agreement seen for hot test

# Model Calibrated to Test: Motor



Only cold test shown, similar model-to-test agreement seen for hot test







Only cold test shown, similar model-to-test agreement seen for hot test



# Model Calibrated to Test: Pillar and Cradle





Only cold test shown, similar model-to-test agreement seen for hot test

TFAWS 2020 – August 18-20, 2020




# Model Calibrated to Test: Cold Plate



Only cold test shown, similar model-to-test agreement seen for hot test


TFAWS 2020 – August 18-20, 2020



Only cold test shown, similar model-to-test agreement seen for hot test




# Thermal Design Study



- Using the dialed-in thermal model ...
- Cases based on conditions predicted in the rack:
  - Cold case – try to get temperatures  $> 15.6^{\circ}\text{C}$  ( $60^{\circ}\text{F}$ )
  - Hot case – make sure pump temperature  $< 70^{\circ}\text{C}$  ( $158^{\circ}\text{F}$ ) and motor temperature  $< 65^{\circ}\text{C}$  ( $149^{\circ}\text{F}$ )
- Analysis predicted no exterior condensation for expected cold operating conditions
- Found these design mods
  - Decrease thermal coupling to the cold plate by eliminating indium shims in lieu of thermal insulator shims
    - Supports beneath cradle
    - Beneath legs of pillars
  - Increase thermal coupling from pump to upper cold block to offset pump and motor temperature increases caused by the thermal insulator shims

**3: Improve thermal coupling to offset pump and motor temperature increases caused by 1 & 2**



**1: 2 places: eliminate indium shim, decrease thermal coupling to equivalent 0.02" G-10**

**2: 4 places: eliminate indium shims, decrease thermal coupling to equivalent 0.04" G-10**




# Design Outcome



- Project decided not to modify the first flight unit, though these changes could be applied to the second flight unit
  - Late in project schedule
  - Decided to accept condensation risk on basis of fungus resistant materials used throughout
- Still need to look at condensation risk
  - Necessity of on-orbit condensation mitigation steps?
    - Inspection?
  - Motor not design for operation in presence of liquid water, wiring not hermetically sealed to housing
    - Motor OK for high humidity noncondensing conditions
    - Pump OK in presence of condensatio



# Condensation Fluid (FloCAD) Model



**Plenum at 29.4C (85F), 2 humidity conditions**

1. 15.6C (60F) dew point = 43% relative humidity  
– nominal worst case
2. 75% relative humidity (24.5C = 76.1F dew point) – extreme worst case

## **Orifice**

**Represents air leak path into the enclosure**  
**Phase specific suction – only water vapor allowed to pass, trapping liquid water in the enclosure**

**2-constituent fluid consisting of**

1. Air (ideal gas)
2. Two-phase water

**Initial condition in tank = same as the plenum**

**Tank**  
**80 in<sup>3</sup> volume**


**Fluid tie, based on 353 in<sup>2</sup> surface area, and 1 inch thick conduction path through air**

**Thermal boundary node: time dependent temperature derived from ASP thermal model**




# Average Interior Surface Temperature


Average Interior Surface Temperature for One Half Cycle



# Leak Size Sensitivity Study


## Sensitivity Check - Condensation vs Leak Size





# Condensation Prediction


## Condensation Response - 200 Half Cycles



— 29.4C, 43% RH, 8.89C LTL

— 29.4C, 43% RH, 3.33C LTL

— 29.4C, 75% RH, 3.33C LTL



# Condensation Predictions

- Ran cyclic simulation with average surface temperature obtained from ASP thermal model

Plenum and Initial Condition	Inlet temperature to ASP cold plate	Comment	Result
29.4C (85F), 43% R.H.	8.9C (48F) – includes precooler warming effect	Reasonable worst case	No condensation
29.4C (85F), 43% R.H.	3.3C (38F) – excludes precooler warming effect	Moderately extreme worst case	Condensation forms on each half cycle, but completely evaporates ... no accumulation
29.4C (85F), 75% R.H.	3.3C (38F) – excludes precooler warming effect	Extreme worst case	Condensation forms on each half cycle, but does not completely evaporate ... condensation accumulates. Assume 3 year mission running continuously at these extreme worst case conditions, ~9 mL predicted to form

- CONCLUSION:** condensation unlikely to form, condensation risk of flying as-is design falls between zero and very small



# References

- 4BCO2-DOC-003A Four Bed CO2 Scrubber Concept of Operations
- 4BCO2-RQMT-004D System Requirements and Verifiaton Matrix
- ISS Pressurized Payloads Interface Requirements Document, SSP 57000 Rev S
- Air Save Pump Assembly and Controller Thermal Characterization Test for Flight Unit, JETS-JE33-20-TLSS-TP-0012, 2/27/2020
- Thermal Desktop (Version 6.0) technical documentation
- Scroll Labs Datasheet and User Guide for SVF-50 Miniature Dry Floating Scroll Vacuum Pump
  
- Acknowledgement to Warren Peters (MSFC-ES62) who created the 4BCO2 cycle diagrams and pseudo animation



# Questions?